



## Shiny high-performance coating for hospitals Semi-gloss high-performance coating for hospitals

### Area of application

All waterproof surfaces except wooden, laminate and cork floors.



ONTOP HOSPITAL  
BRILLIANT

ONTOP HOSPITAL  
SILK

### Application

Prior to application of ONTOP HOSPITAL, perform a basic clean of the floor, rinse with clean water and leave to dry. ONTOP HOSPITAL SILK: Shake well before use. Apply a minimum of two undiluted layers. Allow coating to dry out completely before the next application. No subsequent polishing required as the product adds shine.

### Product characteristics

- Excellent adhesion to residual moisture on floorings – even linoleum
- ONTOP HOSPITAL is easy and quick to apply
- The drying speed allows rapid working
- Excellent durability on all common floors – for a long life span
- Resistant to all common alcoholic hand disinfectants
- Surface treatment: ONTOP HOSPITAL SILK and ONTOP HOSPITAL BRILLIANT can be used in combination
- The characteristic shine lasts for the entire life cycle
- Recommended by leading floor manufacturers
- FIGR-tested; DIN EN 13893 (elastic, laminated and fabric floors – measurement of dynamic coefficient of dry floor surfaces)
- ONTOP HOSPITAL BRILLIANT: Suitable for coating conductive, resilient floor coverings (TÜV Süd material test certificate) in accordance with the requirements of DIN IEC 60167 (max. 2 applications of max. 24 ml per application)

### Note

Do not allow ONTOP HOSPITAL SILK and ONTOP HOSPITAL BRILLIANT to freeze! Depending on climatic conditions, a complete curing of the care film may take up to seven days.

### Technical information

ONTOP HOSPITAL BRILLIANT:

Carton of 3 x 3 l bottles

order No. 00811

ONTOP HOSPITAL SILK:

Carton of 3 x 3 l bottles

order No. 00810

ONTOP HOSPITAL BRILLIANT:

★	Coverage
★ ★	Gloss
★ ★	Durability
★	Care film result
★ ★ ★	Hand disinfectant resistance

ONTOP HOSPITAL SILK:

★ ★	Coverage
★	Gloss
★ ★	Durability
★	Care film result
★ ★ ★	Hand disinfectant resistance

All information contained in our brochures is accurate to the best of our knowledge and experience. No liability can be derived from the information herein. For details about the product, please refer to the safety data sheet. (GB) 0718

pH conc 

0	2	4	6	10	12	14
---	---	---	---	----	----	----

**DR.SCHNELL GmbH & Co. KGaA**  
Taunusstraße 19 · 80807 Munich  
Tel. +49 89 3506080  
info@dr-schnell.com  
www.dr-schnell.com

*Wir leben Hygiene*  
**DR.SCHNELL**  
QUALITÄT UND SERVICE